# 2 PIECE CONVERTIBLE PICNIC TABLE

1



16,000 Woodworking Plans Learn more on: <u>https://bit.ly/ilikewoodworking</u>

## Two bench seats that fold into a picnic table



Two bench seats fold into a picnic table

#### Introduction

This folding picnic table and bench seat combination consists of two individual bench seats with backs that can be folded over and up to form a picnic table capable of seating four adults and two kids.

It is very simple to revert the table back into two separate bench seats whenever that combination is preferred.

The idea itself is not a new one and varying designs have been around for ages. What separates this design from most, is its focus on stability.

The seats backs, which also fold to form the table, have extended support pieces that fit between one another when joined to create a flush and stable tabletop. This clever design factor, along with the angle and placement of the front seat legs, lessens the chance of the folding picnic table and bench seat combination collapsing when it is in the table-and-seat mode.

The folding picnic table and bench seat is structured solely from 150 mm x 50 mm (2" x 6") and 100 mm x 50 mm (2" x 4") wood, making it is a very solid structure.

**Note:** This project is in both metric and imperial. All measurement s are given in millimeter s (mm) first, followed by feet and/or inche s in brackets.

The metric size s are not an exact match to the equivalent imperial size s for practical reasons. A picnic table built using the metric measurements will be approximately 1.6% smaller than a picnic table built using the imperial (ft and in) measurements.

#### About the wood measurements

This project is constructed out of dressed (surfaced or smooth) 150 mm x 50 mm (2" x 6") and 100 mm x 50 mm (2" x 4") wood.


Because this folding picnic table and bench seat combination is most likely to be left outside it is important to use stock that is suitable for exterior use.

The size (width and thickness) of the wood referred to in thi s project is the nominal size. However, because the wood is dressed (surfaced, smooth) the actual size of the wood will be less than the nominal size. For example: 100 mm x 50 mm (2" x 4") wood when dressed will have an actual size of approximatel y 90 mm x 45 mm (1 1/2" x 3 1/2"), and 150 mm x 50 mm (2" x 6") wood when dressed will have an actual size of approximatel y 140 mm x 45 mm (1 1/2" x 5 1/2"). Sizes can vary slightly from place to place but that should not be of too much concern for this project.


The imperial measurements are more suited to North America.

- Because the metric sizes are not an exact match to the equivalent imperial sizes, use one system or the other. Do not mix and match.


## Identifying the pieces



[a] Tabletop board, [b] Seat board, [c] Seat base brace, [d] Seat base end, [e] Arm support, [f] Arm, [g] Decorative fill, [h] Front leg, [i] Rear leg, [k] Tabletop support, [m] Strap hinge, [n] Block underneath seat



Plans - individual pieces and cutting list



[a] & [b] seat boards and tabletop boards - cut 8 pieces from 150 mm x 50 mm (2" x 6") stock.

[c1] seat base brace for unit 1 - cut 1 piece from 150 mm x 50 mm (2" x 6") stock.

[c2] seat base brace for unit 2 - cut 1 piece from 150 mm x 50 mm (2" x 6") stock.

[d] seat base end pieces - cut 4 piece from 150 mm x 50 mm (2" x 6") stock.

[e] arm support - cut 4 piece from 150 mm x 50 mm (2" x 6") stock.

**[f]** LH left-side arm - shape 2 pieces from 150 mm x 50 mm (2" x 6") stock. The grid spacings in the plan drawing represent 25 mm (1"). Use the grid to get the shape, however the dimensions are approximate - measure in place when ready to be fitted (see step 10).

[f] RH right-side arm - shape 2 pieces from 150 mm x 50 mm (2" x 6") stock. The grid spacings in the plan drawing represent 25 mm

(1"). Use the grid to get the shape, however the dimensions are approximate - measure in place when ready to be fitted (see step 10).

[g1] decorative fill for unit 1 - shape 2 pieces from 150 mm x 50 mm (2" x 6") stock.

[g2] decorative fill for unit 2 - shape 2 pieces from 150 mm x 50 mm (2" x 6") stock.


[h] front leg - cut 4 piece from 100 mm x 50 mm (2" x 4") stock.

[i] rear leg - cut 4 piece from 100 mm x 50 mm (2" x 4") stock.

[k] tabletop support


[n] block underneath seat - cut 2 piece from 100 mm x 50 mm (2" x 4") stock.

Plans - side sections






## Plans - front view



## Plans - top view



## Materials List - Altogether you will need....

- 7 meters (24ft) of 100 mm x 50 mm (2" x 4") stock suitable for exterior use.
- 20 meters (67ft) of 150x50 (2" x 6") stock suitable for exterior use.
- Two 200 mm (8") strap hinges and screws to suit.
- Eight 10 mm (3/8") galvanized carriage bolts 110 mm (4 1/2") long.
- 150 wood screws 90 mm (3 1/2") long. Suitable for exterior use.
- 40 galvanized nails 90 mm (3 1/2") long.
- Eight 150 mm (6") x 30 mm (1 1/4') wide galvanized metal strap ties
- Two 10 mm (3/8') thick x 150 mm (6") long galvanized rod or wood dowel

## Instructions

**NOTE:** The picnic table combination comprises of two separate bench seat units. Both units are similar but are not identical.

Throughout this project the bench seat units will be referred to as **unit 1** and/or **unit 2**. Each bench seat unit has a back that can fold up to make a table. Both bench seat units can be fitted together to form a picnic table with seating for four adults and a couple of kids.

#### Step 1. Familiarize yourself

It is easier to take on a project if you're armed with a good understanding of exactly what is involved. This is best achieved by skimming through all the pages to get an overall 'feeling' for the project prior to commencing any practical work.

#### Step 2. Cut all the pieces

Cut all the individual pieces to the lengths and shapes as shown by the **individual pieces** detail on page seven. Begin by cutting the longest pieces first to minimize wastage.

Most of the pieces can be cut with a compound miter saw or even a circular saw but a jig-saw or similar will be needed to shape the arms [f], the tabletop supports [k] and the decorative fills [g]. The **cutting list** and the **individual piece** sizes, lengths and shapes are on page seven and the **piece identification** is on page six.


#### Step 3. Make the seat base

Make up the seat bases for units 1 & 2 as shown in the **plans** and also as shown in **fig.1**.

Each base comprises of a brace piece **[c]** and two base end pieces **[d]**.

The brace piece **[c]** for **unit 1** is 1290 mm (52") long and the brace piece **[c]** for **unit 2** is 1400 mm (56") long.


Pre-drill the screw holes in the base end pieces **[d]** and then screw them to the ends of the brace piece **[c]**.



Attach metal strap ties at all meetings to help prevent 'wobble'. See fig.1

#### Step 4. The seat boards

Place two seat boards **[b]** on each base. Position as shown in **fig.2** and ensure that the overhangs at both ends of each board are equal. Hold each board in place with a couple of nails and then screw the seat boards to the base with 90mm (3 1/2") wood screws through pre-drilled shank holes.




## Step 5. The legs

Turn the seat units upside down. Position (see **fig.2**, **fig.3** and/or the plans) and clamp the legs to the base ends **[d]**.

Drill and bolt the legs to the base ends using one 10 mm (3/8") galvanized carriage bolt for each leg. Further secure with three 90 mm (3 1/2") screws for each leg.

Add a block **[n]** to the front face of the base brace **[c]** to give the front seat board **[b]** extra support. Fix the block to both the brace and the seat board.



#### Step 6. Prepare the tabletop


Each pair of tabletop boards need to be fastened together in the middle to ensure that the seams stay flush.

This can be achieved by inserting a 10 mm (3/8") galvanized rod or wood dowel into pre-drilled holes located centrally along the edge of each tabletop board. See **fig.4** 

Take care when marking for the drill holes. Clamp two boards together back to back and square a line across the edges of the boards centrally from each end. Intersect the line with another line centrally from each face side.

In simple terms, ensure that the hole mark is in the middle of the edge of both boards.

Drill a 10 mm (3/8") diameter hole 90 mm (3 1/2") deep into the edge of both boards, insert the galvanized rod or wood dowel and tap the boards together.



### Step 7. The tabletop and arm supports

Determine where to position the arm support **[e]** on the tabletop support **[k]**.

To do this, hold the tabletop support **[k]** in position on the seat unit and then sit the arm support **[e]** level on top of a closed hinge. Hold the arm support **[e]** in position against the tabletop support **[k]**.


Note: The hinge is not fixed in place at this time. It is just used as a packer to determine the correct height of the arm support **[e]**.

Next, mark the position of the arm support [e] on the tabletop support [k].



Make up a second pair in mirror image of the first.

You will then need to repeat the process for the second bench seat unit.




### Step 8. Fix the tabletop boards to the tabletop supports

Using the seat benches as work platforms, lay the tabletop supports **[k]** across the seat boards directly above, and in line with the base ends **[d]**.

The tabletop supports **[k]** should then automatically be the right distance apart.

Position the tabletop boards **[a]** as shown in **fig.6**. Ensure that the overhangs at both ends of the tabletop boards are equal and then screw the tabletop boards **[a]** to the tabletop supports **[k]** with 90mm (3 1/2") wood screws through pre-drilled holes.




Note: The spacings between the tabletop supports **[k]** for **unit 1** will be different to that of **unit 2**.

When finished, the tabletop supports **[k]** on **unit 1** must be able to fit between the tabletop supports **[k]** on **unit 2**. See the **plans** on page ten.

#### Step 9. Join the table to the seat

Hold each tabletop assembly upright in position on their respective seat units and mark the positions of the arm supports **[e]** on the seat boards **[b]**. See **fig.7a**.

Fold the seat over to the table position. With the end of the arm supports **[e]** on the mark, prop the table level and then fit the hinges making sure that the hinge screws have maximum hold.



#### Step 10. The arm


The length of the arm **[f]** is most important as it holds the tabletop on the same plane as the seat (i.e. level) when in the 'table position'.

Mark and cut each arm around their respective tabletop supports **[k]** and shape to suit. See the **individual pieces** on page seven.

The length of the arms **[f]** should be the distance between the tabletop boards **[a]** and the base ends **[d]** when the tabletop is level or on the same plane as the seats. See **fig.8a**.

Fold each seat back to the 'seat position' and screw the arms [f] to the arm supports [e] through pre-drilled shank holes. See **fig.8b**.

Finally, shape and screw a decorative fill **[g]** to the bottom of each tabletop support **[k]** and arm support **[e]**.



A few pictures of the 2 piece convertible picnic table



#### Photos of users handiwork

P hoto by people who have undertaken this project.





Want even more woodworking projects? Discover a collection of **16,000 Woodworking Plans** and turn your ideas into reality!

Learn more on: <u>https://bit.ly/ilikewoodworking</u>